

To change names on the phone display panel, do the following:

- Connect to the Inter-tel Axxess system.
- Go to AXCESS System → Devices and Feature Codes → Stations
- Click in the description and Username fields to change.

